

How to Improve the Image Quality of Reolink Cameras

There are some settings you can set to get better image quality for Reolink cameras. Please refer to the instruction below.

Applies to: All Reolink Cameras

Note: If you want to get a clearer image when you operate this camera remotely (LiveView, Playback and upload the recording to Cloud), please ensure that you have a good network environment. If the network where you access this camera is poor, we suggest you switch to the Fluent mode to operate the camera, otherwise you will meet the file lost and stream delay.

There are six functions you can check the image quality of Reolink Cameras.

- **LiveView**
- **Playback**
- **Email attachment**
- **Download the recording**
- **Recordings uploaded to the FTP**
- **Recordings uploading to the Cloud**

1. Change the Encode Settings

If the network is stable, it is recommended to set the bitrate to the highest setting.

Refer to: [Set Up the Record Encode for Reolink Cameras](#)

2. Change the Installation Environment (Applies to all above functions)

- Avoid IR reflection
- Avoid the strong light
- Avoid solid color
- Make sure the subject is within the illumination range

3. Change the Functional settings

- For **LiveView/Playback/Download recordings**, change the stream mode to Clear/High. Refer to: [How to Change Stream Mode in Live Viewing](#)
- For **FTP uploading**, change the **File Type**. Refer to: [How to Set up FTP via Reolink Client \(New Client\)](#)
- For the **Email attachment**, it only supports the Fluent mode transformation. Therefore, you can't find the option for image quality adjustment.
- For **Cloud uploading**, change the **Video Resolution**. Refer to: [How to Upload Record Videos to Reolink Cloud Server](#)

4. Update Reolink Device and Software to the Latest Version

- Reolink Device Firmware: Updating the firmware of your Reolink device is crucial to ensure optimal performance. [Reolink Firmware Update Guide](#)
- Reolink App/Client: Update the App from your phone's App Store, or download the latest version of the Reolink Client from the Reolink website. [How to Upgrade My Reolink Client and Reolink App](#)

Notes:

1. If you meet a problem when you access this camera remotely, you can access it locally for verification before contacting us.
2. If you meet an image issue when you operate the camera in the third-party software, you can try to operate it in Reolink software in advance before [contacting Reolink Support](#).